# $X_{\text{TEND-2/T}}$

# 10Base-2/T Converter

ETP-20038T Installation Guide



#### COPYRIGHT

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, whether electronic, mechanical, photo copying, recording or otherwise, without the prior written permission of the publisher.

#### FCC WARNING

This equipment has been tested and found to comply with the limits for a class A device, pursuant to part 15 of FCC rules. These limits are designed to provide reasonable protection against harmful interference in a commercial installation. This energy and, if not installed and used in accordance with the instructions, may cause harmful interference, in which case, the user will be required to correct the interference at user's own expense.

#### WARRANTY

UNICOM Electric, Inc. is so confident of the quality of our products that we are now extending our warranty period to 5 years against any defects in workmanship.

Note: UNICOM guarantees this product providing it is used in the manner it was intended. Damages caused by customer misuse, abuse, and neglect will cause any implied or written guarantees to be null and void. \*See "Terms and Conditions of Sates" for complete warranty.

Congratulations! You have just purchased a quality product from UNICOM, Electric, Inc. UNICOM has been committed to the design and manufacture of networking products for the data and voice communications industry since 1986.

UNICOM is also dedicated to the continuing development of modern communication technology. UNICOM has successfully developed a complete line of UTP (Unshielded Twisted-Pair) products for IBM Token Ring, 3X,AS/400, 3270, Ethernet, Hewlett Packard, AppleTalk, RS-232, DEC and other data communication systems.

You can be confident that your new UNICOM product is reliable. UNICOM products are 100% tested before shipment and backed by the industry's best 5 Year Warranty.

UNICOM

File: ETP-20038T.doc

## CONTENTS


I.	Overview	1
II.	Thin Ethernet Terminator Switch	2
III.	10Base-T Connection Switch	3
IV.	LED Indications	4
V.	Set-up Procedures	5-6
VI.	Troubleshooting	7
VII.	Specifications	8

## OVERVIEW

#### I. Overview

This booklet is designed as a guide for the easy installation of XTEND-2/T, UNICOM's 10Base-2 to 10Base-T Converter.

The 10Base-2/T Converter is designed to connect an existing 10Base-2 Thin Ethernet adapter card or 10Base-2 network to a 10Base-T system. The converter works by simply repeating the signals from 10Base-2 to a suitable format for transmission over UTP (Unshielded Twisted Pair) cables to a 10Base-T hub or workstation.





#### II. Thin Ethernet Terminator Switch



 ON - Set the terminator at the "ON" Position when the converter is placed at the end of the segment. See set-up, page 5.




 OFF - Set the terminator at the "OFF" Position when the converter is placed in the middle of the segment. See set-up, page 5.

## SWITCH


#### III. Connection Switch



 Hub Connection - Set the connection switch to the Hub position for a Hub connection.



 Workstation Connection - Set the connection switch to the W/S position for a Workstation connection.



1=TX+ 2=TX-3=RX+ 6=RX-



#### IV. LED Indicators

This collision indicator blinks when data collision occurs COL on either 10Base-T or 10Bas-2 Port. LINK/RCV With this indicator continuously ON, data link is operating and converter is ready to receive data. When this indicator blinks, data transmission is occurring on the 10Base-T port. This indicator is continuously "ON" while the converter POWER is receiving power from the external power adapter. When this indicator is blinking, data is being received BNC/RCV from 10Base-2 Port.

## SET-UP


#### V. Set-Up Procedures - 10Base-2 Connection

#### Example 1

Converter is placed on the end of a segment.

#### Procedure

- Set Terminator Switch to "ON" (50ohm)
- Plug coaxial cable into BNC connector.




#### Example 2

Converter is placed in the middle of a segment.

#### Procedure

- Set Terminator Switch to "OFF"
- Plug coaxial cable into BNC connector.



## SET-UP


#### V. Set-Up Procedures - 10Base-T Connection

#### Example 1

10Base-T Hub Converter.

#### Procedure

- Set Terminator Switch to Hub position.
- Connect RJ-45 Jack with pin-to-pin patch cord.




#### Example 2

10Base-T Workstation Connection.

#### Procedure

- Set connection switch to Workstation position.
- Connect the RJ-45 Jack with a pin-to-pin patch cord



## TROUBLESHOOTING

#### VI. Troubleshooting

Symptom	Possible Cause	Solution	
Power not "ON"	Bad power connection	Check external power adapter	
LINK/RVC not "ON"	- Wrong connection switch - Bad connection	-Check Connection switch setting -Check patch cord	
COL LED	Wrong Terminator setting	Check Terminator setting Check coaxial	

Technical Hotline 1-800-346-6668

### SPECIFICATIONS

#### VII. Specifications

Standard IEEE 802.3 10-Base-T, 10Base-2 standards

Interface BNC connector for thin Ethernet RI-45 lack for 10Base-T Ethernet

Cable Type RG-58 coaxial cable for thin Ethernet connection;

Category 3,4,or 5 UTP cable for 10Base-T UTP cable

Technique Base band

Standard IEEE 802.3 10Base-2 and 10Base-T Ethernet

Terminator Switch Two position (OFF or ON) for BNC

Connection Switch Two position switch for Hub or Workstation settings

Temperature 0° to 55°C (Standard Operating) Humidity 10% to 90%(non-condensing)

Dimensions 4.2"x2.2"x0.8"

Power Adapter 9V DC input,1 Amp

EMI Meets FCC Class A subpart B of Part 15 Requirements



908 Canada Court City of Industry, CA 91748 U.S.A. e-mail: info@ unicomlink.com http://www.unicomlink.com Technical Support: 1-800-346-6668

1997 by UNICOM, UNITY IN COMMUNICATIONS, UNCOM and XTEND-2/T are Trademarks of UNICOM Electric, Inc. IBM Token Ring, 3X, AS/400, 3270, Ethernet, Hewlett Packard, AppleTalk, RS-232, and DEC are Registered Trademarks of their respective Companies. All specifications and materials are subject to change without notice.

REF: ETHERNETWANUALIX-TEND-2T